

9 channel mode:

Channel	Value	Function
1	000-255	Master dimmer (0-100%)
2	000-255	Red (0-100%)
3	000-255	Green (0-100%)
4	000-255	Blue (0-100%)
5	000-255	White (0-100%)
6	000-010	Blackout
	011-016	Red
	017-022	Flame Red
	023-028	Deep Golden Amber
	029-034	Millennium Gold
	035-040	Gold Amber
	041-046	Orange
	047-052	Chrome Orange
	053-058	Deep Amber
	059-064	Spring Yellow
	065-070	Lime Green
	071-076	JAS Green
	077-082	Fern Green
	083-088	Moss Green
	089-094	Primary Green
	095-100	Dark Green
	101-106	Green
	107-112	Medium Blue/Green
	113-118	Light Blue
	119-124	Lighter Blue
	125-130	Steel Blue
	131-136	Half CT Blue
	137-142	Full CT Blue
	143-148	State Blue
	149-154	Double CT Blue
	155-160	Medium Blue
	161-166	Just Blue
	167-172	Deep Blue
	173-178	Blue
	179-184	Congo Blue
	185-190	Surprise Pink
	191-196	Fuchsia Pink
	197-202	Follies Pink
	203-208	Special Rose Pink

9 channel mode (cont.):

Channel	Value	Function
6 (cont.)	209-214	Pink
	215-220	Moroccan Pink
	221-226	Warm White
	227-232	Cold White
	233-255	White
7	000-015	No function
	016-031	Program 1
	032-047	Program 2
	048-063	Program 3
	064-079	Program 4
	080-095	Program 5
	096-111	Program 6
	112-127	Program 7
	128-143	Program 8
	144-159	Program 9
	160-175	Program 10
	176-191	Program 11
	192-207	Program 12
	208-223	Program 13
	224-239	Program 14
	240-255	Program 15
8	000-255	Program Speed (slow-fast)
9	000-010	No function
	011-255	Strobe (slow-fast)